


## Honeywell

| No | Model                    | Photo   | Specification  |
|----|--------------------------|---|--|
| 1  | Honeywell 1200g-2USB-1   |    | Honeywell Voyager 1200g, 1D, multiHF, kit (USB, coiled), black |
| 2  | Honeywell 1202G-2USB-5BF |    | Honeywell Voyager 1202g-bf, BT, 1D, kit (USB), black           |
| 3  | Honeywell 1202g-2USB-5   |   | Honeywell Voyager 1202g, BT, 1D, multiHF, kit (USB), black     |
| 4  | Honeywell 1250g-2USB-1   |  | Honeywell Voyager 1250g, 1D, multiHF, kit (USB), black         |
| 5  | Honeywell 1400g2D-2USB-1 |  | Honeywell Voyager 1400g, PDF, 2D, multiHF, kit (USB), black    |
| 6  | Honeywell 1450g1D-2USB-1 |  | Honeywell Voyager 1450g, 1D, imager, multiHF, kit (USB), black |
| 7  | Honeywell 1452g2D-2USB-5 |  | Honeywell Voyager 1452g, BT, 2D, multiHF, kit (USB), black     |

|    |                             |  |  |
|----|-----------------------------|--|--|
| 8  | Honeywell 1900GSR-2USB      |   | Honeywell Xenon 1900, 2D, SR, kit (USB), black                   |
| 9  | Honeywell YJ-HH360-R-2USB-1 |   | Honeywell Youjie HH360, 1D, multi-IF, kit (USB), black           |
| 10 | Honeywell HH400-R1-2USB-1   |   | Honeywell Youjie HH400 , 2D Area-Imaging Scanner ( USB ) , black |
| 11 | Honeywell MK7120-31A38      |  | Honeywell Orbit 7120, 1D, kit (USB), black                       |
| 12 | Honeywell MK9520-37A38      |  | Honeywell Voyager 9520, 1D, kit (USB), black                     |